



How to batch set up the maintenance plan item maintenance process (Document)

Users log in to the OLISS web side and click "Maintenance → Maintenance Plan Management" in order to enter the maintenance plan management interface, click "Add", select vessel, department and click "Confirm" to enter the select maintenance plan interface. In the interface, according to the need to check the target maintenance items and then click "Next Step" into the update maintenance plan interface.

In this interface, click "Data Initialization", enter the maintenance plan import interface, click the "Export The Maintenance Plan List" to export maintenance plan form, then specify the maintenance process in the form can pull down selection maintenance process, after the maintenance plan form modification, click the "Import Maintenance Plan" to upload, data upload success, click the "Submit".



Maintenance Plan Import

5. Click "Data Initialization"

6. Click "Export The Maintenance Plan List" to export maintenance plan form

Export the plan list, modify and import it, so as to batch update.

Import Maintenance Plan Import the maintenance plan template

Operation Log

NO.	Import Time	Import Status	Processing Sta...	Processing En...	Attachment	Operator	Operation
1	2024-12-23 15:4 5:30	done	2024-12-23 15:4 5:30	2024-12-23 15:4 5:32		潘俊杰	View Details

Exported Maintenance Plan Form:

	U	V	W	X	Y	Z	AA
1	Days of Task Generated In Advance	Display No.	Upload Permits Attachments	Consumption of related items	Attachment must be uploaded	Old Vessel Identification	Designated Maintenance Process*
2	7	-100	Required	Not Required	No	No	24887972_抄送
3	7	0	Optional	Not Required	No	No	0_默认
4	7	0	Optional	Not Required	No	No	24940044_测试保养
5	7	0	Optional	Not Required	No	No	24887972_抄送
6	7	0	Optional	Not Required	No	No	14424439_正常保养
7	7	0	Optional	Not Required	No	No	7737160_新增保养
8	7	0	Optional	Not Required	No	No	0_默认
9	72	0	Optional	Not Required	No	No	0_默认
10	7	0	Optional	Not Required	No	Yes	0_默认
11	7	0	Optional	Not Required	No	No	0_默认
12	7	0	Optional	Not Required	No	No	0_默认
13	7	0	Optional	Not Required	No	No	0_默认
14	7	0	Optional	Not Required	No	No	0_默认
15	7	0	Optional	Not Required	No	No	0_默认
16	7	0	Required	Not Required	No	No	0_默认
17	7	0	Optional	Required	Yes	Yes	0_默认
18	7	1	Required	Not Required	No	No	0_默认
19	7	1	Optional	Not Required	No	No	0_默认
20	7	1	Optional	Not Required	No	No	14424439_正常保养
21	7	1	Optional	Not Required	No	No	0_默认
22	7	1	Required	Not Required	No	Yes	0_默认

7. Specify the maintenance process in the form can pull down selection maintenance process

Maintenance Plan Import

8. After the maintenance plan form modification, click the "Import Maintenance Plan" to upload

Import Maintenance Plan Import the maintenance plan template

Operation Log

NO.	Import Time	Import Status	Processing Sta...	Processing En...	Attachment	Operator	Operation
1	2024-12-23 15:4 5:30	done	2024-12-23 15:4 5:30	2024-12-23 15:4 5:32		潘俊杰	View Details



Add | Data Initialization | **Select Maintenance Plan**

All Invalid | Restore-all | Reset

Main	Update Type	Maintenance Type	Update Content	Maintenance Item	Maintenance Request	P.I.C.	Maintena...	Jan	Feb	M	Invalidate This Page
1123	Update	General	Modified项目编码, 项目标识, 指定保...	Deck, outer plate of hull 甲板, 船壳外板	Check for corrosion, da mage, deformation, w...	CO	3Months7D ay	22			View Edit Delete Invalid

1 Total | 10Total/Page

9.Finally click "Submit"



Save | **Submit** | Cancel